


Installation Guide for all iBEAM PTZ Cameras with Cellular Communication




- 1 Attach your PTZ camera to a pole or other mounting surface using the provided straps.
- 2 Attach communication box to pole/mounting surface using the provided straps.
- 3 Gently pull the cable gland out of its seated location, then feed the network cable into the box and reseal the gland.
- 4 Plug the network cable into the open port of the PoE power supply.
- 5 Plug the unit into the appropriate power source as indicated on the PoE power supply.
- 6 After the camera has been mounted and plugged in for 15-20 minutes, the Primary Contact will receive an email* with information regarding how to view your camera.
- 7 ***If the Primary Contact doesn't see this email from our Support Team, please reach out to them at 800.403.0688 ext. 2 and they can verify the system is online.**

The Support Team is available Monday through Friday 8:00 am - 5:00 pm Mountain Standard Time. When calling, if they're assisting another customer please leave a voicemail and they'll return your call as soon as possible.
- 8 Enjoy!

This installation guide applies to:

iBEAM PTZ HD
iBEAM PTZ 4K


For camera specifications and dimensions, please refer to the iBEAM Camera spec sheets.




Scan the **QR code** to watch the iBEAM PTZ camera installation video.



Comm Box Pole Mount



Camera Pole Mount



Camera pole mount (preassembled)